

Schlebach Quadro

RAKE WALL TRANSITION

- 1.) Secure rake support angle through slots w/ #10-12 x 1" pancake head wood screw @ 4"oc.
- 2.) Turn panel edge up 1 1/2".
- 3.) Apply a continuous strip of sealant tape to the inside leg of the upturned edge
- 4.) Set ledge trim on sealant tape, and secure with 1/4-14 x 7/8" HWH Tek/1 @ 12"oc.
- 5.) Apply a continuous strip of sealant tape to the top of the ledge trim.
- 7.) Install the transition trim. Secure to closure zee with 1/4-14 x 7/8" HWH Tek/1 fasteners at 12"oc.
- 6.) Fill open hem of counter flash with urethane sealant. Interlock the two trims and secure counter flash to wall with the appropriate fastener.

