

# Schlebach Quadro

## RAKE WALL TRANSITION

- 1.) Temporarily attach transition trim at ends w/ #10-12 x 1" pancake head wood screws
- 2.) Attach receiver through transition with #10-12 x 1" pancake head wood screws @ 12"oc.
- 3.) Apply butyl sealant over the heads of the wood screws. as shown.
- 4.) Apply a bead of urethane sealant inside the open hem of the receiver trim.
- 5.) Install panels so that the field cut end is engaged into open hem of the receiver trim, and fully embedded into the urethane sealant.
- 6.) Apply urethane sealant between the receiver and the transition trim. Tool to a fillet.

